Install Lines in Alphabetical order.

3/8 Vacuum Cap

A2:

FRONT

B:

C:

A1:

D:

-8 Orb Fittings

Oil Drain/Return port -6orb

Coolant Return Port-6 Orb to 1/2" barb